

ADMINSTRATOR

Product Archive (PLU)

The PLU contains the target weight of the product, the tare, code and description, association with a barcode for recalling with bar-code reader The PLU can be set on the terminal or imported from "file" The inclusion of the target weight is calculated automatically the threshold values according to the relevant regulations (76/211 / EEC) Ability to change the weight thresholds to meet the needs of non-EU countries or to different control policies

Production lines / packaging archives

The line code combined with batch control, allows you to go back to the production plant and correct any defects. The archive line contains the code for line and its relative description.

Data can be set on the terminal or imported from "file"

Operator Archive

The operator code combined with batch control, allows you to trace the shift during which the inspections have taken place. The archive contains the code for of the operator or shift

Data can be set on the terminal or imported from "file"

Lot Archive

Consultation of lots opened or suspended and batch already closed and still in memory (up to a limit settable days)

Planning of lots to be checked

Archive weighed

Consultation of precise weighing data for batch Lot reports

Summary data of the batch in PDF or CSV format exportable via USB, Ethernet, WiFi and printable Export / import data in CSV format, Import archives Operator and PLU

Export archives Operator, PLU, Lot and Weighing

Management of tare samples

In the case of differing tare values it is not possible to predetermined the tare value: in this case it is necessary to weigh the empty conatiners identifying them and recall after filling for the correct evaluation of the net weight.

Closure and batch validation

On reaching the required number of samples in the single or double sampling (if defective samples are more than allowed), the batch is closed.

Result of the batch accepted or rejected is immediately displayed

Print (if applicable) of the analysis report of the batch

Transmission of relative PDF and CSV

OPERATOR

Operational activation of Lot via (keyboard / scanner) Guided weighing operations (also "multi-lot", colours, histogram, etc ...)


The operator opens a lot selecting it with barcode reader or touch screen; following the directions of the terminal it is readied to weigh the required number of samples.



Indication of the single weights*




 The touch screen changes colour to indicate the status, from Green, Yellow, Red.



Example screen showing graphical distribution of weighings

Diade Control System:

Electronic terminal **DD1010** + Weighing Platform and Software for the control management.




Do You Want To Connect a Second Scale For Higher Precision?

Version with stainless steel platform and loadcell in aluminum

Dimension of	Standard Version	
Plate (mm)	Capacity (kg)	Division (g)
300x240	0,3 ÷ 12	0,1 ÷ 2
400x400	12	2









Società Cooperativa Bilanciai Campogalliano
41011 Campogalliano (MO) Italy - Via S. Ferrari, 16
Tel. 059 / 89.36.11 - Fax 059 / 52.70.79
Servizio Assistenza Clienti - Tel. 059 / 89.36.12 - Fax 059 / 52.72.94
www.coopbilanciai.it - cb@coopbilanciai.it

